

www.RamsetStore.com


(888) 378 - 1105

Sales@RamsetStore.com

# DC RAM 300s • DC RAM 302s SWING - INSTRUCTION MANUAL

# INSTRUCTION MANUAL

HIGH TRAFFIC SWINGING  
GATE OPERATORS



**DC RAM 300**



**DC RAM 302**

**LOW PROFILE**



**For Class I, II, III, IV  
Vehicular Gate  
Operators**

## IMPORTANT SAFETY REQUIREMENTS BY UL STANDARDS

- a) Install the gate operator only when:
- 1) The operator is appropriate for the construction of the gate and the usage Class of the gate,
  - 2) All openings of a horizontal slide gate are guarded or screened from the bottom of the gate to a minimum of 1.83 m (6 ft) above the ground to prevent a 57.2 mm (2-1/4 inch) diameter sphere from passing through the openings anywhere in the gate, and in that portion of the adjacent fence that the gate covers in the open position,
  - 3) All areas of the moving vertical pivot gate panel from the bottom of the gate to the top of the gate or a minimum of 1.83 m (72 in) above grade, whichever is less, that pass by a fixed stationary object, and in the area of the adjacent fence that the gate covers during the travel of the gate, shall be designed, guarded or screened to prevent a 57 mm (2-1/4 in) diameter sphere from passing through such areas.
  - 4) All exposed pinch points are eliminated or guarded, and
  - 5) Guarding is supplied for exposed rollers.
  - 6) The operator instructions shall list the maximum number of open and close entrapment protection devices capable of being connected to the operator.
- b) The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate access opening. The pedestrian access opening shall be designed to promote pedestrian usage. Locate the gate such that persons will not come in contact with the vehicular gate during the entire path of travel of the vehicular gate.
- c) The gate must be installed in a location so that enough clearance is supplied between the gate and adjacent structures when opening and closing to reduce the risk of entrapment. Swinging gates shall not open into public access areas.
- d) The gate must be properly installed and work freely in both directions prior to the installation of the gate operator. Do not over-tighten the operator clutch or pressure relief valve to compensate for an improperly installed, improperly functioning, or damaged gate.
- e) For gate operators utilizing Type D protection:
- 1) The gate operator controls must be placed so that the user has full view of the gate area when the gate is moving,
  - 2) The placard as required by 62.1.6 shall be placed adjacent to the controls,
  - 3) An automatic closing device (such as a timer, loop sensor, or similar device) shall not be employed, and
  - 4) No other activation device shall be connected.
- f) Permanently mounted controls intended for user activation must be located at least 1.83 m (6ft) away from any moving part of the gate and where the user is prevented from reaching over, under, around or through the gate to operate the controls.

Exception: Emergency access controls only accessible by authorized personnel (e.g. fire, police, EMS) may be placed at any location in the line-of-sight of the gate.

- g) The Stop and/or Reset button must be located in the line-of-sight of the gate. Activation of the reset control shall not cause the operator to start.
- h) A minimum of two (2) WARNING SIGNS shall be installed, in the area of the gate. Each placard is to be visible by persons located on the side of the gate on which the placard is installed. Also see 62.1.1.
- i) For gate operators utilizing a non-contact sensor in accordance with 32.1.1:
- 1) See instructions on the placement of non-contact sensors for each Type of application,
  - 2) Care shall be exercised to reduce the risk of nuisance tripping, such as when a vehicle, trips the sensor while the gate is still moving, and
  - 3) One or more non-contact sensors shall be located where the risk of entrapment or obstruction exists, such as the perimeter reachable by a moving gate or barrier.
- j) For a gate operator utilizing a contact sensor in accordance with 32.1.1:
- 1) One or more contact sensors shall be located where the risk of entrapment or obstruction exists, such as at the leading edge, trailing edge, and post-mounted both inside and outside of a vehicular horizontal slide gate.
  - 2) One or more contact sensors shall be located at the bottom edge of a vehicular vertical lift gate.
  - 3) One or more contact sensors shall be located at the pinch point of a vehicular vertical pivot gate.
  - 4) A hardwired contact sensor shall be located and its wiring arranged so that the communication between the sensor and the gate operator is not subjected to mechanical damage.
  - 5) A wireless device such as one that transmits radio frequency (RF) signals to the gate operator for entrapment protection functions shall be located where the transmission of the signals are not obstructed or impeded by building structures, natural landscaping or similar obstruction. A wireless device shall function under the intended end-use conditions.
  - 6) One or more contact sensors shall be located on the inside and outside leading edge of a swing gate. Additionally, if the bottom edge of a swing gate is greater than 152 mm (6 in) but less than 406 mm (16 in) above the ground at any point in its arc of travel, one or more contact sensors shall be located on the bottom edge.
  - 7) One or more contact sensors shall be located at the bottom edge of a vertical barrier (arm)

# RESPONSIBILITIES OF THE INSTALLER / GATE TECHNICIAN

\*\*\* RAMSET GATE OPERATORS SHOULD ONLY BE INSTALLED, MAINTAINED OR SERVICED BY A QUALIFIED, EXPERIENCED GATE TECHNICIAN WITH THE APPROPRIATE TRAINING.

- READ & UNDERSTAND THE ENTIRE INSTRUCTION MANUAL BEFORE STARTING ANY INSTALLATION
- USE THE PROPER OPERATOR. TAKE INTO CONSIDERATION:
  - CATEGORY (SLIDE, SWING OR OVERHEAD)
  - TYPE (STANDARD, UPHILL, COMPACT, ...ETC.)
    - All measurements and capabilities in this manual are for standard installations. All other types of installations may reduce the capabilities and measurements in this manual.
  - GATE CLASS (I, II, III or IV) see UL gate classification section
  - GATE WEIGHT & TRAVEL
- DO NOT EXCEED THE EQUIPMENTS SPECIFICATIONS AND CAPABILITIES OF THE OPERATOR AND HARDWARE.
- MAKE SURE THE OPERATOR HAS A SECURE FOUNDATION (see installation specifications section)
- WHEN SERVICING A GATE OPERATOR ALWAYS PERFORM AN INSPECTION OF THE ENTIRE GATE SYSTEM (GATE, GATE OPERATOR, INSTALLATION & ELECTRICAL WIRING) AND MAKE ANY AND ALL SUGGESTIONS, TO THE PROPERTY OWNER, TO BRING THEIR GATE SYSTEM INTO COMPLIANCE WITH ALL UL 325 AND ASTM F2200 SAFETY STANDARDS.
- A SIGNED WAIVER DOES NOT NULIFY THE INSTALLER / TECHNICIANS LIABILITY DUE TO THE FACT THAT IT HAS NO SUBSTANCE IN LITIGATION INVOLVING AN INJURED PARTY WHO DID NOT SIGN THE WAIVER.
- WHEN NECESSARY, INSTALL SURGE / LIGHTNING SUPPRESSION AND GROUND RODS.
- SAFETY IS THE PRIMARY CONCERN WHEN INSTALLING A GATE OPERATOR
- MAKE SURE TO FOLLOW ALL UL 325 AND ASTM F2200 SAFETY CODES.
- ANY NON-AUTOMATED GATE THAT IS TO BE AUTOMATED SHALL BE UPGRADED TO CONFORM TO THE ALL ASTM F2200 STANDARDS.
- WHEN THE GATE OPERATOR REQUIRES REPLACEMENT, THE EXISTING GATE SHALL BE UPGRADED TO CONFORM TO ALL ASTM F2200 AND UL325 SAFETY STANDARDS.
- WHEN THE GATE OF AN AUTOMATED GATE SYSTEM REQUIRES REPLACEMENT, THE NEW GATE SHALL CONFORM TO ALL ASTM F2200 STANDARDS.
- ONLY USE UL 325 COMPLIANT ACCESSORIES & EQUIPMENT.
- ONLY USE THE APPROVED ENTRAPMENT PROTECTION DEVICES LISTED IN THIS MANUAL.
- MAKE SURE ALL ENTRAPMENT ZONES ARE PROTECTED BY APPROVED ENTRAPMENT PROTECTION DEVICES.
  - ENTRAPMENT ZONE: Locations between a moving gate and a counter opposing edge or surface where entrapment is possible up to 6 ft. above grade. Such locations occur if during any point in travel the gap between a moving gate and fixed counter opposing edges or surfaces is less than 16 inches.
- APPROVED ENTRAPMENT PROTECTION DEVICES:

EMX NIR 50-325  
EMX IRB-RET  
EMX IRB-MON

OMRON E3K-R10K4  
SECO-LARM E931-S50RRGQ  
SECO-LARM E936-S45RRGQ

MILLER EDGE - PRIME GUARD  
MILLER EDGE - REFLECTI GUARD

- NO SAFETY DEVICES SHOULD EVER BE BYPASSED, REMOVED OR OMITTED BY THE INSTALLER / TECHNICIAN.
- ALL CONTROLS MUST BE LOCATED AT LEAST 6 FEET AWAY FROM ANY PART OF THE GATE OPERATOR OR MOVING GATE AT ALL TIMES
- INTERIOR CONTROL STATIONS SHOULD BE INSTALLED SO THAT THE USER HAS A DIRECT LINE OF SIGHT TO THE GATE AREA BEING CONTROLLED.
- PHOTO EYES SHOULD BE INSTALLED WITHIN 5 INCHES FROM THE GATE PANEL AND A MAXIMUM HEIGHT OF 27.5 INCHES.
- ALL EXPOSED PINCH POINTS ARE ELIMINATED OR GUARDED.
- ALL EXPOSED ROLLERS ARE GUARDED.
- WARNING SIGNS MUST BE PERMANENTLY AFFIXED TO THE GATE PANEL IN A HIGHLY VISIBLE PLACE THAT CAN BE EASILY SEEN FROM BOTH SIDES OF THE GATE.
- FOR PEDESTRIAN ACCESS IN THE VICINITY OF AN AUTOMATED VEHICULAR GATE, A SEPARATE PEDESTRIAN GATE SHALL BE PROVIDED.
  - THE PEDESTRIAN GATE SHALL BE INSTALLED IN A LOCATION SUCH THAT A PEDESTRIAN SHALL NOT COME IN CONTACT WITH A MOVING VEHICULAR ACCESS GATE.
  - A PEDESTRIAN GATE SHALL NOT BE INCORPORATED INTO AN AUTOMATED VEHICULAR GATE PANEL.
- GATES SHALL BE DESIGNED, CONSTRUCTED AND INSTALLED SUCH THAT THEIR MOVEMENT SHALL NOT BE INITIATED BY GRAVITY WHEN AN AUTOMATIC OPERATOR IS DISCONNECTED.
- ALL OPENINGS SHALL BE DESIGNED, GUARDED, OR SCREENED FROM THE BOTTOM OF THE GATE TO THE TOP OF THE GATE OR A MINIMUM OF 72" ABOVE GRADE, WHICHEVER IS LESS, TO PREVENT A 2 ¼" DIAMETER SPHERE FROM PASSING THROUGH THE OPENINGS ANYWHERE IN THE GATE, AND IN THAT PORTION OF THE ADJACENT FENCE THAT THE GATE COVERS IN THE OPEN POSITION. THE GATE PANEL SHALL INCLUDE THE ENTIRE SECTION OF THE MOVING GATE, INCLUDING ANY BACK FRAME OR COUNTERBALANCE PORTION OF THE GATE.



# IMPORTANT INFORMATION FOR THE HOMEOWNER

## **WARRANTY INFORMATION:**

- Completely fill out and mail-in (Via certified mail) your WARRANTY REGISTRATION CARD within 90 days of the installation to:  
Ramset Automatic Gate Systems, Inc.  
9116 De Garmo Ave  
Sun Valley, CA 91352
- The WARRANTY REGISTRATION CARD can also be filled out on our website <RAMSETINC.COM>.
- Read and understand your warranty certificate.
- Ramset's warranty only covers the operator against manufacturer's defects.
- Ask the installer / technician what the warranty on their service is. (Labor is not covered under Ramset's warranty).
- All Warranty issues & claims must be redeemed by a gate technician.

## **BEFORE YOUR TECHNICIAN LEAVES:**

- Ask your technician about all of the features of your new Ramset Gate Operator.
- Make sure the gate moves smoothly without excessive shaking, bouncing or noise.
- Make sure all of your accessories are properly functioning (remotes, keypads, telephone entry systems, exit loops, safety loops, phantom loops, edge sensors...etc.).
- Make sure that your technician gives you the following documentation that is enclosed inside every operator:  
1) Warranty Registration Card    2) Warranty Certificate    3) Inspection Sheet
- Have your technician give you a demonstration of how to use the emergency release:  
1) Foot Pedal    2) Chain Drop    3) Hand lever release    4) Hand trolley release
- Have the technician show you the gate operator breaker in your electrical panel.  
- A label is provided with every operator to clearly mark the breaker.
- Make sure the safety photo eyes or edges are properly installed on your gate system.  
- A minimum of 1 Photo eye/edge protecting the closing direction.
- THIS ENTRANCE IS FOR VEHICLES ONLY. Pedestrians should be provided with a separate entrance.  
- The pedestrian gate should be located so that the moving vehicular access gate does not cross or come in contact with the pedestrian gate at any time.  
- A pedestrian gate shall not be incorporated into an automated vehicular gate panel.
- Warning signs must be mounted on each side of the gate (inside and outside) in a highly visible area.

## **AFTER YOUR TECHNICIAN LEAVES:**

- Always keep a good relationship with your technician and keep their phone number handy for future maintenance or emergencies.
- **All issues should be directed to your technician.**
- Whenever possible, turn off the circuit breaker to the operator before using the emergency release system.
- No one except a qualified, experienced gate technician should ever remove the cover or access door from the gate operator.
- Only a qualified, experienced gate technician should work on, maintain, clean, repair or service the gate operator.
- Keep gates properly maintained. Have a qualified, experienced gate technician service the gate operator system & gate hardware approximately every 6 months to a year.
- Frequently check all safety devices for proper operation. This includes photo eyes, loops, edges...etc.
- Frequently check your emergency release and battery back-up system (if applicable) for proper operation.
- Never let children operate or play with gate controls. Keep the controls away from children.
- Never let children play in the area around the gate or gate operator.
- Never let anyone ride, climb under or climb over the gate.
- Always keep people, children and objects away from the gate while the gate is in operation.
- No one should cross the area of a moving gate.
- Keep the area around the gate operator clean and free of debris.
- Keep the area around the gate operator free from insects and rodents. Insects and rodents can cause damage to the gate operator, which is not covered by the warranty.

## UL GATE CLASSIFICATIONS

**CLASS I - Residential Vehicular Gate Operator** - A vehicular gate operator (or system) intended for use in garages or parking areas associated with a residence of one-to four single families.

**CLASS II - Commercial / General Access Vehicular Gate Operator** - A vehicular gate operator (or system) intended for use in a commercial location or building such as a multi-family housing unit (five or more single units), hotel, garages, retail store, or other buildings accessible by or servicing the general public.

**CLASS III - Industrial / Limited Access Vehicular Gate Operator** - A vehicular gate operator (or system) intended for use in an industrial location or building such as a factory or loading dock area or other locations not accessible by or intended to service the general public.

**CLASS IV - Restricted Access Vehicular Gate Operator** - A vehicular gate operator (or system) intended for use in a guarded industrial location or building such as an airport security area or other restricted access locations not servicing the general public, in which unauthorized access is prevented via supervision by security personnel.

## GENERAL SPECIFICATIONS

MODEL	RAM 300	RAM 302
MAX GATE LENGTH	18 Feet	
MAX GATE WEIGHT	1200 lbs.	
MOTOR	24V BLDC, Brushless	
WATTAGE	24VDC, 235W	
DUTY CYCLE	CONTINUOUS DUTY	
APPLICATION	RES. / COM. / IND.	
CHASSIS PLATING	3/16" - GOLD/ZINC PLATED	
EMERGENCY RELEASE	BATTERY BACK UP OR FOOT PEDAL	BATTERY BACK UP OR HAND LEVER
DIMENSIONS	27" x 16 1/2" x 20"	16 1/2" x 23" x 13 1/2"
GATE SPEED	90° in ~15 seconds (speed depends on the geometry of arms)	

**\*All measurements and capabilities in this manual are for standard installations. All other types of installations may reduce the capabilities and measurements in this manual.**

## RECOMMENDED ELECTRICAL CONNECTION

A 3-wire, 115VAC electrical circuit with a 15 amp independent (dedicated) circuit breaker for single operator and a 20 amp independent (dedicated) circuit breaker for primary / secondary systems. Low voltage control wires must be run in a separate conduit to the operator.

**NOTE: ALWAYS CONSULT AND FOLLOW ALL LOCAL BUILDING AND ELECTRICAL CODES PRIOR TO INSTALLATION. PERMANENT WIRING IS TO BE EMPLOYED AS REQUIRED BY LOCAL CODES. GROUNDING THE OPERATOR IS ESSENTIAL FOR SAFETY AND PROPER OPERATION.**

# INSTALLATION SPECIFICATIONS - CONCRETE PAD




**WARNING** ALWAYS CONSULT AND FOLLOW ALL LOCAL BUILDING AND ELECTRICAL CODES PRIOR TO INSTALLATION.

## CONCRETE PAD CONSTRUCTION

Dimensions given for the pad are based on soil bearing shear of 2000 P.S.F. These figures may have to be adjusted depending on local soil conditions.

1. Construct form for mounting the pad according to dimensions shown in Figure 1, 2 & 3.
2. Locate the mounting pad according to dimensions given in illustration.
3. Level the top edge of the form.
4. Set reinforcing bars and wire mesh
5. Mix concrete, pour mixture into form. Level and finish surface after pouring is complete.
6. Allow the pad to cure for 48 hours, and remove the forms.




MODEL	A	B	C	D	E	F
R300	24"	20"	12"	13 1/2"	6 3/4"	2 1/2"
R302	27"	18"	10 1/4"	10 3/8"	6 3/4"	2 1/2"


\* All measurements are given as minimums

## FOOTPRINTS

**Figure 2** RAM 300 FOOTPRINT



**Figure 3** RAM 302 FOOTPRINT






# INSTALLATION SPECS (CONT.)


## RAM 300

**Figure 4**




## RAM 302

**Figure 5**




## GATE TRAVEL ADJUSTMENT

**Figure 6**



The gate travel is adjusted by loosening the limit cams and positioning them until the proper travel is achieved.


**Figure 7**



## EMERGENCY RELEASE & TORQUE LTD TENSION


**Figure 7**

Torque Ltd. tension bolts need to be tightened to a min. of 40lbs. above the weight of the gate in order to avoid slipping.



**Emergency Arm Release.** Secure gate, loosen knob, pull up on pivot to release the arm.

**Figure 8**



Tighten the handle to avoid slipping. Use the handle and bolt to increase the tension.

**Emergency Arm Release** Secure the gate. Loosen the handle & push the gate.

# OPERATOR LOCATION & ARM LENGTHS




## WARNING


MAKE SURE THERE ARE NO PINCH POINTS CREATED WHEN THE ARMS ARE IN THE FULLY OPEN POSITION.

USE THE LENGTH OF THE FLAT BAR ON THE GATE BRACKET AND PIVOT TO ADJUST THE ARMS FOR PROPER LENGTHS BEFORE WELDING THEM.

**Figure 9 OPERATOR LOCATION**



**Figure 10 ARM LENGTHS**




<b>A</b> (GATE LENGTH)	<b>B</b> (HINGE TO OP. BRACKET)	<b>C</b> (HINGE TO OP. SHAFT VERT.)	<b>D</b> (HINGE TO OP. SHAFT - HOR.)	<b>F</b> (SHORT ARM LENGTH)	<b>G</b> (LONG ARM LENGTH)
<b>UNDER 12'</b>	<b>44"</b>	<b>34"</b>	<b>14" - 16"</b>	<b>28"</b>	<b>38"</b>
<b>13' TO 18'</b>	<b>50"</b>	<b>40"</b>	<b>14" - 16"</b>	<b>32"</b>	<b>42"</b>

\* The measurements given are for a level gate that opens 90 degree.

# COMPACT & CUSTOM INSTALLATIONS

**Figure 11**



1. Get a tape measure.
2. Close the gate completely.
3. Measure the distance from the pivot center to the gate bracket bolt. We will call this measurement 'X'.
4. Open and secure the gate.
5. Bend the tape measure (see figure 11) to create a pivot point.
6. Place the end of the tape measure (0") on the gate bracket bolt.
7. Place measurement 'X' (from step 3) of the tape measure onto the pivot center.
8. Move the pivot point of the tape measure until it is about 3 inches from the obstruction (wall).
6. 'H' is the length of the short arm.
7. 'J' is the length of the long arm.




# LOOP LOCATION & INSTALLATION



## WARNING

LOOP SENSORS CANNOT BE USED TO MEET UL325 REQUIREMENTS. PHOTO EYES, EDGES OR THE EQUIVALENT ARE NEEDED TO MEET UL325 REQUIREMENTS.


Figure 12



- REVERSING LOOPS:**  
 Hold the gate open or reverse a closing gate if a vehicle is detected.
- PHANTOM LOOP:**  
 Placed under the swing path of a swing gate. This loop will check before the gate closes to see if a vehicle is within the swing path, if a vehicle is within the swing path the gate will not move.
- INSIDE LOOP:**  
 Placed just outside of the swing path of the gate. Stops the gate from opening until it is cleared.
- EXIT LOOP:**  
 Opens and holds the gate open.

## DUAL PARTING GATES - PRIMARY & SECONDARY

- Connect a 3-wire, shielded cable (not supplied), between 'SEC XCOM' on the logic board in the primary unit and 'XCOM' on the AC driver board in the secondary unit.
- The primary/secondary wires should be ran in a conduit separate from the power.



The right/left dip switch on the driver board in each unit will have to be set accordingly.

The logic board in the secondary unit is not needed and can be removed.

## ENTRAPMENT TYPES & PROTECTION MEANS



**WARNING**

**ALL ENTRAPMENT AREAS NEED TO BE PROTECTED BY A MONITORED ENTRAPMENT PROTECTION DEVICE.**

- Every swing gate operator requires a minimum of:
  - 1 entrapment protection device in the opening direction, and
  - 2 entrapment protection devices in the closing direction.
- One in each direction is covered by the inherent ERD system (Type A). Therefore, at least one additional photo eye, edge sensor or equivalent is required to be added, by the installer, in the closing direction.
- Since every installation is different, it is up to a qualified, trained technician to make sure that ALL entrapment areas are protected by an entrapment protection device.
- It is also up to a qualified, trained technician to determine what types and how many devices are needed.
- A Maximum of 10 monitored entrapment devices may be connected to your operator, depending on direction of travel and type of device.

Horizontal Swing  
Entrapment protection types  
A, B1, B2, C or D

Note – The same type of device shall not be utilized for both entrapment protection means.


<b>Type A</b>	Inherent entrapment protection system.
<b>Type B1</b>	Non-contact sensor (photoelectric sensor or the equivalent).
<b>Type B2</b>	Contact sensor (edge device or the equivalent).
<b>Type C</b>	Inherent force limiting, inherent adjustable clutch or inherent pressure relief device.
<b>Type D</b>	Actuating device requiring continuous pressure to maintain opening or closing motion of the gate.

Minimum Quantity of Entrapment Protection Means		
	Opening	Closing
Horizontal Swing Gate	1*	2*

\*The Inherent ERD System (Type A) counts as 1 entrapment protection device in each direction. Therefore, a minimum of one more exterior entrapment protection device (type B1 or B2) needs to be installed in the closing direction.

## EMX - NIR-50-325 - PHOTO EYE WIRING DIAGRAM

**Figure 13**



# ENTRAPMENT PROTECTION AREA



## WARNING

MAKE SURE ALL ENTRAPMENT ZONES ARE PROTECTED BY APPROVED ENTRAPMENT PROTECTION DEVICES.

**ENTRAPMENT ZONE:** Locations between a moving gate and a counter opposing edge or surface where entrapment is possible up to 6ft above grade. Such locations occur if during any point in travel the gap between a moving gate and fixed counter opposing edges or surfaces are less than 16 inches

In order to prevent serious injury, bodily harm or death from a moving gate:


- Entrapment protection devices must be installed to cover all entrapment danger areas and locations during a gates opening and closing cycles.

Since every installation is different, it is up to a qualified and trained technician to determine:

- All possible Entrapment areas & locations
- The amount and type of entrapment protection devices that are needed.


Approved anti-entrapment devices (10K method):

- EMX NIR 50-325
- EMX IRB-MON
- EMX IRB-RET
- OMRON - E35-R10K4
- MILLER EDGE - PRIME GUARD
- MILLER EDGE - REFLECTI-GUARD
- SECO-LARM - "ENFORCER" - E931-S50RRGQ
- SECO-LARM - "ENFORCER" - E936-S45RRGQ



- 1 - HINGED POST AREA - PINCH POINT
- 2 - LEADING EDGE - ENTRAPMENT
- 3 - POST - ENTRAPMENT
- 4 - LOWER GATE EDGE - ENTRAPMENT

- 5 - BACK PLANE ZONE - ENTRAPMENT
- 6 - INTERIOR ZONE - SAFETY
- 7 - EXTERIOR ZONE - SAFETY





# LOGIC & AC DRIVER BOARD - L.E.D. LAYOUT


## LOGIC BOARD



- **POWER** - Low voltage is present.
- **OPENING** - The gate is opening.
- **STOPPED** - The gate is stopped.
- **CLOSING** - The gate is closing.
- **FULL OPEN** - The open limit switch is being triggered.
- **FULL CLOSED** - The close limit switch is being triggered.
- **3BTN OPEN** - 3-button station "open" button is being pressed.
- **3BTN STOP** - 3-button station "stop" button is being pressed.
- **3BTN CLOSE** - 3-button station "close" button is being pressed.
- **PR/CO WARN** - Pre-warn / Constant-warn relay is active.

- **SAFETY** - Safety / Reversing device is being triggered.
- **FIREBOX** - Firebox device is being triggered.
- **EXIT** - Exit device is being triggered.
- **PHANTOM** - Phantom device is being triggered.
- **RADIO** - Radio device is being triggered
- **MAG/SOL** - The magnetic / solenoid lock relay is active.
- **INS DET** - The inside detector is being triggered.
- **LED 1** - Not used at this time.
- **LED 2** - Not used at this time.
- **LED 3** - Not used at this time.
- **PRI ERD** - ERD on the primary unit is being triggered.
- **PRI XCOM** - Communication on the primary unit is sending / receiving information.
- **SEC ERD** - ERD on the secondary unit is being triggered.
- **SEC XCOM** - Communication on the secondary unit is sending / receiving a signal
- **SEC FP** - The foot pedal switch on the secondary unit is being triggered.
- **ENTRAP 1** - A monitored entrapment device on Entrapment #1 is being triggered.
- **ENTRAP 2** - A monitored entrapment device on Entrapment #2 is being triggered.
- **ENTRAP 3** - A monitored entrapment device on Entrapment #3 is being triggered.
- **ENTRAP 4** - A monitored entrapment device on Entrapment #4 is being triggered.
- **ENTRAP 5** - A monitored entrapment device on Entrapment #5 is being triggered.

# LOGIC BOARD DIP SWITCHES & PUSHBUTTONS



## DIP SWITCH 'A'

### 'A' 1, 2 & 3 - AUTOMATIC CLOSE TIMER

'0' = ↓ DOWN    '1' = ↑ UP

SWITCH	1	2	3	GATE OPEN DURATION
	0	0	0	DISABLED
	0	0	1	0 SECONDS
	0	1	0	5 SECONDS
	0	1	1	10 SECONDS
	1	0	0	15 SECONDS
	1	0	1	30 SECONDS
	1	1	0	45 SECONDS
	1	1	1	60 SECONDS

### 'A' 4 - PRE WARN ALARM

DOWN	Normal Operation
UP	Triggers a closed contact between 'CON/PRE WARN' outputs (located on relay connections plug) for 3 seconds before the gate moves in any direction.

### 'A' 5 - CONSTANT WARN ALARM

DOWN	Normal Operation
UP	Triggers a closed contact between 'CON/PRE WARN' outputs (located on relay connections plug) whenever the motor is running.

\* If both 'A' 4 & 'A' 5 are in the up position then there will be a closed contact on the con/pre warn outputs for 3 seconds before and as the motor is running.

### 'A' 6 - SECURE CLOSE

DOWN	Normal Operation
UP	When power is lost and then regained, if all devices are clear & it's safe, the gate will close

### 'A' 7 - ONE PASS

DOWN	Normal Operation
UP	While the gate is opening, if the rev loop input is triggered and then cleared, the gate will immediately start closing. If the rev loop is then triggered again, before the gate is fully closed, the gate will stop and stay at rest until the rev loop input is cleared. Once the rev loop input is cleared, the gate will resume closing. At any time if a valid open signal is received, the gate will open.

### 'A' 8 - RADIO CYCLE

DOWN	The gate will close, if it's on the open limit. Otherwise, the gate will always open.
UP	The gate will close if it's on the open limit. The gate will open if it's on the close limit. If in travel, the gate will stop with the 1st command and reverse with a second command.

## DIP SWITCH 'B'

### 'B' 1 - FULL REVERSE ERD

DOWN	Normal Operation. If an obstruction is sensed, the gate will stop and reverse for 1 second.
UP	If an obstruction is sensed: Opening - Gate will stop and reverse for 1 sec. Closing - Gate will stop and reverse until fully open.

### 'B' 2 - MAGNETIC/SOLENOID LOCK

DOWN	Magnetic Lock - MAG/SOL relay is shorted when the gate is closed or closing.
UP	Solenoid Lock - MAG/SOL relay is shorted for 2 seconds when the gate starts to open.

### 'B' 3 thru 8 - NOT USED AT THIS TIME

## DIP SWITCH 'C'

### 'C' 1 - 3B STOP

DOWN	3-button station - The 'STOP' input is active. A normally-closed contact switch must be present between 'common' and 'stop'
UP	3-button station - The 'STOP' input is bypassed. No connection between 'common' and 'stop' is needed.

### 'C' 2 - TYPE D\*\*

DOWN	Type D device* is not being used to meet UL325 standards.
UP	Type D device* is being used to meet UL325 standards. This disables all inputs other than the 3-button station. Maintained signal required.

\* Type D device - A pushbutton or equivalent that required a maintained pressure for activation.

\*\*For gate operators utilizing Type D protection:

- 1) The gate operator controls must be placed so that the user has full view of the gate area when the gate is moving.
- 2) The placard as required by UL3.25 - 62.1.6 shall be placed adjacent to the controls.
- 3) An automatic closing device (such as a timer, loop sensor, or similar device) shall not be employed, and
- 4) No other activation device shall be connected.

## PUSHBUTTONS




### E.P. LEARN Monitored Entrapment Protection Learn Button

Activates the monitored entrapment protection learning process. This button is to be pressed after the entrapment protection devices are connected to the board. During this process, the LEDs will blink. The processor will check for devices connected. Once this process is complete, the LEDs will return to normal operation and the processor will monitor for the 'learned' devices connected. (For further information, see the Entrapment Protection section of this manual.)



# ENTRAPMENT PROTECTION DIP SWITCHES & PLUGS

## ENTRAPMENT PROTECTION



**D**

**E**

### DIP SWITCH 'D & E'

#### 'D'1, 'D'2 & 'D'3 - \*M.E.P. #1

'0' = ↓DOWN '1' = ↑UP

SWITCH	D1	D2	D3	GATE OPEN DURATION
	0	0	0	NO DEVICE CONNECTED
	0	0	1	NO DEVICE CONNECTED
	0	1	0	PHOTO EYE ON CLOSING
	0	1	1	EDGE ON CLOSING
	1	0	0	PHOTO EYE ON OPENING
	1	0	1	EDGE ON OPENING
	1	1	0	PHOTO EYE ON OPENING & CLOSING
	1	1	1	EDGE ON OPENING & CLOSING

#### 'D'4, 'D'5 & 'D'6 - \*M.E.P. #2

'0' = ↓DOWN '1' = ↑UP

SWITCH	D4	D5	D6	GATE OPEN DURATION
	0	0	0	NO DEVICE CONNECTED
	0	0	1	NO DEVICE CONNECTED
	0	1	0	PHOTO EYE ON CLOSING
	0	1	1	EDGE ON CLOSING
	1	0	0	PHOTO EYE ON OPENING
	1	0	1	EDGE ON OPENING
	1	1	0	PHOTO EYE ON OPENING & CLOSING
	1	1	1	EDGE ON OPENING & CLOSING

#### 'D'7, 'D'8 & 'E'1 - \*M.E.P. #3

'0' = ↓DOWN '1' = ↑UP

SWITCH	D7	D8	E1	GATE OPEN DURATION
	0	0	0	NO DEVICE CONNECTED
	0	0	1	NO DEVICE CONNECTED
	0	1	0	PHOTO EYE ON CLOSING
	0	1	1	EDGE ON CLOSING
	1	0	0	PHOTO EYE ON OPENING
	1	0	1	EDGE ON OPENING
	1	1	0	PHOTO EYE ON OPENING & CLOSING
	1	1	1	EDGE ON OPENING & CLOSING

\* M.E.P. = Monitored Entrapment Protection

#### 'E'2, 'E'3 & 'E'4 - \*M.E.P. #4

'0' = ↓DOWN '1' = ↑UP

SWITCH	E2	E3	E4	GATE OPEN DURATION
	0	0	0	NO DEVICE CONNECTED
	0	0	1	NO DEVICE CONNECTED
	0	1	0	PHOTO EYE ON CLOSING
	0	1	1	EDGE ON CLOSING
	1	0	0	PHOTO EYE ON OPENING
	1	0	1	EDGE ON OPENING
	1	1	0	PHOTO EYE ON OPENING & CLOSING
	1	1	1	EDGE ON OPENING & CLOSING

#### 'E'5, 'E'6 & 'E'7 - \*M.E.P. #5


'0' = ↓DOWN '1' = ↑UP

SWITCH	E5	E6	E7	GATE OPEN DURATION
	0	0	0	NO DEVICE CONNECTED
	0	0	1	NO DEVICE CONNECTED
	0	1	0	PHOTO EYE ON CLOSING
	0	1	1	EDGE ON CLOSING
	1	0	0	PHOTO EYE ON OPENING
	1	0	1	EDGE ON OPENING
	1	1	0	PHOTO EYE ON OPENING & CLOSING
	1	1	1	EDGE ON OPENING & CLOSING



Set the dip switches to match with the corresponding \*M.E.P. plug.


All four (4) wires must be connected for the \*M.E.P. to properly function.




- OPEN - Used to protect during the open cycle.
- CLOSE - Used to protect during the close cycle.
- PHOTO/EDGE - The type of device that is being connected.  
DOWN = photo eye  
UP = edge connector



# LOGIC BOARD PLUGS



- **REV LOOP** - Used to stop the gate from closing. Holds the gate open when maintained. This is a non-monitored connection. Monitored devices should be connected to the entrapment protection plugs.
- **FIREBOX** - Used to open the gate for emergency vehicles. Requires a maintained signal. Overrides all safety devices.  
 \*ONLY USE FOR EMERGENCY VEHICLES.
- **EXIT** - Used to open the gate and/or hold the gate open.
- **PHANTOM** - Used to hold the gate open when it's on the open limit. Once the gate starts to close this has no effect. Works with a loop detector or photo eye to cover the area that the gate travels over.
- **RADIO** - Used to open, stop and close the gate. Full control.
- **INSIDE DET** - Stops a swing gate from hitting an obstruction when opening. When triggered, the gate will stop and wait until the detector is cleared. Once the detector is cleared, the gate will continue to open.
- **MAG/SOL** - Used with a magnetic lock or solenoid. See dip switch 'B4'. This is a relay output. A separate transformer or power source is needed to work with this connection.  
 MAG: The relay is closed when the gate is closing or closed.  
 SOL: The relay is closed for 3 seconds as it begins to open, then releases.
- **SEC XCOM** - 3-wire conductor, preferably shielded, used to communicate between the primary and secondary units.



# (M.E.P.) MONITORED ENTRAPMENT PROTECTION QUICK SETUP GUIDE



**IMPORTANT: MAKE SURE THE M.E.P. DEVICE YOU ARE USING IS A UL325 MONITORED ENTRAPMENT DEVICE USING THE 10K METHOD**

1. Slide Gate Requirements:
  - a. Closing - Minimum 1 photo eye or edge sensor.
  - b. Opening - Minimum 1 photo eye or edge sensor.
2. Swing Gate Requirements:
  - a. Closing - Minimum 1 photo eye or edge sensor.
  - b. Opening - No minimum requirement.
3. M.E.P. #1
  - a. Connect 4 wires (24V, GND, N.O. & COM) to the #1 plug (located on the right edge of the logic board # 1 thru #5)
  - b. Set the corresponding dip switches  
[MEP 1 = Dip switch section 1 (C1, C2, C3)...]
    - if protecting the opening, turn the 'OPEN' dip switch on.
    - if protecting the closing, turn the 'CLOSE' dip switch on.
    - if using a photo eye, turn the 'PHOTO/EDGE' switch off.
    - if using a edge sensor, turn the 'PHOTO/EDGE' switch on.
4. M.E.P. #2 (if applicable)
  - a. Connect 4 wires (24V, GND, N.O. & COM) to the #2 plug (located on the right edge of the logic board # 1 thru #5)
  - b. Set the corresponding dip switches  
[MEP 2 = Dip switch section 2 (C4, C5, C6)...]
    - if protecting the opening, turn the 'OPEN' dip switch on.
    - if protecting the closing, turn the 'CLOSE' dip switch on.
    - if using a photo eye, turn the 'PHOTO/EDGE' switch off.
    - if using a edge sensor, turn the 'PHOTO/EDGE' switch on.
5. Continue through M.E.P. #5 or until all MEP devices are connected.
6. Once all M.E.P. devices are connected, push & hold the 'EP LEARN' button.
  - a. When LEDs 'ENTRAP 1' through 'ENTRAP 5' start flashing, release the button.
  - b. All 5 LEDs will go off for about 3 seconds.
  - c. All 5 LEDs will blink 3 times.
  - d. The corresponding LEDs with the MEPs that were connected will turn solid for 3 seconds. (Make sure the number of LEDs match the number of MEPs connected. If the numbers don't match, check the wiring connection and repeat step 6.